



iPad 4 CDMA Plastic Spacer Replacement

Prereq only.

Written By: Walter Galan



INTRODUCTION

Prereq only.



TOOLS:

- [Spudger](#) (1)
-

Step 1 — Plastic Spacer



- Using the flat end of the spudger, pry the plastic spacer away from the rear case.
- Remove the plastic spacer from the iPad.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-11-21 07:18:51 PM.